

## Introduction

This handbook covers all current versions of the LR3 models and, together with the other books in your literature pack, provides all the information that you need to derive maximum pleasure from owning and driving your new vehicle.

For your convenience, the handbook is divided into sections, each dealing with a different aspect of the vehicle. These are listed on the Contents page and you will find it worthwhile to take a little time to read each one, and get to know your LR3 as soon as you possibly can. The more you understand before you drive, the greater the satisfaction once you are seated behind the steering wheel.

The specification of each vehicle will vary according to territorial requirements and also from model to model within the vehicle range. Some of the information published in this handbook, therefore, may not apply to your particular vehicle.

To include changes made after the handbook is printed, it is sometimes necessary to issue one or more handbook supplements. When reading this handbook, check the literature pack for possible supplements.

Any further updates will be posted on the Land Rover internet site and can be accessed at [www.landrover.com](http://www.landrover.com) in the **OWNERS** area.

**\* An asterisk appearing within the handbook text identifies features or items of equipment that are either optional, or are only fitted to some vehicles in the model range.**

Land Rover operates a policy of constant product improvement and therefore reserves the right to change specifications without notice at any time. Whilst every effort is made to ensure complete accuracy of the information in this handbook, no liabilities for inaccuracies or the consequences thereof can be accepted by the manufacturer or the retailer, except in respect of personal injury caused by the negligence of the manufacturer or the retailer.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form, electronic, mechanical, photocopying, recording or other means without prior written permission from the Service Division of Land Rover.



As part of Land Rover's environmental policy, this publication is printed on paper made from chlorine-free pulp.

# Handbook Contents

---

## Quick Overview

Quick Overview . . . . .	7
Reporting Safety Defects . . . . .	7
Gas Station Information . . . . .	20

## General Information

General Information . . . . .	23
-------------------------------	----

## Controls & Instruments

Keys & Handsets . . . . .	29
Locks & Alarms . . . . .	34
Seats . . . . .	41
Seat Belts . . . . .	59
Child Restraints . . . . .	65
Airbag SRS . . . . .	70
Steering Column . . . . .	78
Door Mirrors . . . . .	79
Facia Controls . . . . .	81
Instruments . . . . .	83
Settings Option* . . . . .	85
Message Center* . . . . .	87
Trip Computer* . . . . .	99
Warning Indicators . . . . .	100
Audible Warnings . . . . .	106
Lamps & Indicators . . . . .	107
Wipers & Washers . . . . .	111
Horn . . . . .	115
Electric Windows . . . . .	116
Sunroof . . . . .	119
Heating & Ventilation . . . . .	121
Interior Equipment . . . . .	131
Loadspace Cover . . . . .	148
Audio System . . . . .	151
In-Car Telephones . . . . .	153
Voice Recognition . . . . .	154
Land Rover Homelink® . . . . .	156

## Driving & Operating

Starting & Driving . . . . .	161
Catalytic Converter . . . . .	165
Fuel Filling . . . . .	166
Park Distance Control . . . . .	170
Automatic Transmission . . . . .	172
Transfer Gearbox . . . . .	177

Cruise Control . . . . .	180
Brakes . . . . .	182
Dynamic Stability & Traction Control . . . . .	188
Hill Descent Control . . . . .	190
Air Suspension . . . . .	193
Terrain Response . . . . .	199
Towing . . . . .	206
Towing Eyes . . . . .	214
Towing the Vehicle . . . . .	217
Load Carrying . . . . .	219
Front Lighting Systems . . . . .	220

## On-road Driving

On-road Driving . . . . .	221
---------------------------	-----

## Off-road Driving

Off-road Driving . . . . .	225
Off-road Driving Techniques . . . . .	229

## Maintenance

Maintenance . . . . .	235
Hood Opening . . . . .	238
Under-hood Covers . . . . .	239
Engine Compartment . . . . .	240
Engine Oil . . . . .	242
Cooling System . . . . .	243
Brakes . . . . .	245
Power Steering . . . . .	246
Washers . . . . .	247
Wiper Blades . . . . .	249
Battery . . . . .	251
Tires . . . . .	254
Cleaning & Vehicle Care . . . . .	268
Identification Numbers . . . . .	271
Parts & Accessories . . . . .	272

## Roadside Emergency

Wheel Changing . . . . .	275
Emergency Starting . . . . .	286
Fuses . . . . .	288
Bulb Replacement . . . . .	297

## Technical Data

Lubricants & Fluids . . . . .	311
-------------------------------	-----

# Handbook Contents

---

Capacities . . . . .	313
Engines . . . . .	314
Electrical System . . . . .	315
Steering . . . . .	316
Wheels & Tires . . . . .	317
Vehicle Weights . . . . .	319
Dimensions . . . . .	320
Towing . . . . .	321